




EASEE


STOTELĖS PRIJUNGIMO INSTRUKTAŽAS

Susikūrus stotelę mūsų programėlėje, reikės atlikti šiuos veiksmus:

1. Nueikite į <https://portal.easee.com/>, Paspauskite **Fleet Management**




2. Pasirinkite savo stotelę






3. Apačioje paspauskite **Company Access**



4. Spauskite **Operator**





5. Apačioje **pažymėkite varnelę** ir spauskite **Change**

A dark-themed modal window with a title bar. Inside, there is a checked checkbox labeled "Attention!". Below it, a paragraph of text reads: "Remember that if you change operator company, your existing operator company will not be able to provide you with their services." At the bottom, there are two rounded buttons: a blue one labeled "Change" and a red one labeled "Remove".

6. Sąrašė susiraskite **CircleLink** ir jį pasirinkite


A dark-themed screen titled "Operator" with a back arrow and a close button. A message states: "Together with our partners, we can offer you an even better charging solution, enabling you to do even more with your Easee products on this charging site." Below this is a search bar with the placeholder "Filter" and the text "CircleLink" entered. A result is shown below the search bar: a square icon with a briefcase and the text "CircleLink" underneath it.

7. Apačioje paspauskite **Assign**


A dark-themed screen showing a single blue rounded button labeled "Assign" at the bottom.



8. Savo stotelės SN (serial number) galima sužinoti pasirinkus **Chargers**:



9. Atsidarę CircleLink programėlę nueikite į savo stotelės nustatymus:



Paspauskite **krumpliaračį**



11:14 Station configuration ✓

General information

Station Name

Laumzīrgis

Station Id

U0000002SBZH17SQ

⚠ Changing Station ID breaks the OCPP connection. Change with care.

ID tags (Authorization tokens)

ID tag 1

ba71bb22ed274f8da7c4

ID tag 2

ID tag 3

ID tag 4

ID tag 5

Station id pakeiskite ī savo stotelēs SN (serial number)